

1 Read all directions before plugging in dispenser.

IMPORTANT: Do not plug in dispenser until step 5. This guide is a general reference to help you quickly and easily set up your Pure Water Dispenser® 200k Series. For complete setup, operating and safety instructions, reference the owner's manual.

2 Place dispenser on level floor surface at least 4 inches from wall.

3 Install base plates.
Align side plate with base and slide into base until in locked position. Repeat for second slide plate.



4 Insert bottle on dispenser.
Remove tamper-evident seal from plastic bottle cap. (Do NOT remove plastic cap if using a NO-SPILL water bottle.) Load water bottle by lifting and inserting it onto the probe. Be sure bottle is fully aligned with dispenser, centered over the probe and fingers or other body parts are clear of underside of bottle. Apply slight pressure until plug pushes in and bottle is securely seated. Water will flow into the tank causing air bubbles.

5 Plug in dispenser to a GFCI outlet.



6 Prime water system.
Depress hot water lever to fill the hot tank until water flows continuously. This may take about 1 minute. Repeat steps for cold tank. The cold tank may take about 3 minutes.



7 Activate heating function.
IMPORTANT: Ensure priming of the hot water system is complete before proceeding. Turn on hot tank heater switch located on rear of dispenser. Optimum water temperature will be reached after several hours.

To learn more, visit water.com